





Each night...



At the end of every day, please carry out the following:

Turn the water supply to the bath off. Go round to the back of the van and locate the white circular valve which allows water to feed from the large rear water tank to the pump which then pumps it into the bath. When the valve is open the arrows will be inline with the pipe. To Turn the valve off, turn the valve 90 degrees to the right so that the arrows are horizontal to the pipe. This will stop any water in the rear tank syphoning through into the bath over night.



Correct Valve.



Valve open



Valve closed.

In winter...

If there is the potential for over night frost then we recommended emptying the water pipes as well as closing the valve just as a precaution. To do this, firstly close the valve as described above. Next, turn on the water pump that pumps the water from the rear tank to the bath. Now go to your bath, push the lever to Rinse and turn on the bath, this will draw water from the rinse tank and as the level goes down it will activate the pump which will pump the remaining water through the pipes. As the water valve is closed it cannot draw any water from the big tank, which will in turn empty the pipes. Remember to open the valve again in the morning so you have water!